

Installation Guidelines



1 Clear base of all debris



2 Use brickies mortar mix with waterproofing agent



3 Ensure first course is level both directions



4 Basements and retaining walls require reinforcing



5 Use the Benex Adhesive Gun to apply Benex Adhesive



6 Apply Benex Adhesive to horizontal and vertical ends



7 Maximum span between control joints is 8m



8 Use notched Benex for horizontal reinforcing



9 Check blockwork for plumb and straight each course



10 Can be core-filled for added strength where required



11 Use type 17 wood screws for fixings



12 Apply acrylic or cement renders as manufacturers specifications